

DISCLAIMER: NO RESPONSIBILITY ACCEPTED FOR NON-ADHERENCE TO THESE INSTRUCTIONS

KAOKO Safety Warning:

The KAOKO Throttle Stabilizer is an aftermarket accessory. Any misunderstood, abused or incorrectly installed motorcycle accessory is a safety hazard that could cause injury or death. It's the rider's responsibility to under- stand the operation and purpose for which the KAOKO Throttle Stabilizer is designed, namely, for cruising, only when safe to do so. At all other times the control should be disengaged. The KAOKO Throttle Stabilizers are to be used only by experienced and responsible riders. See reverse of page for full indemnity.

Note: An adjustment to throttle assembly position may be necessary to suit KAOKO Throttle Stabilizers. The throttle assembly position on aftermarket bars, and some OEM bars, is adjustable. The assembly can marginally be re-positioned along the handle bars slightly loosening the throttle assembly clamp screws, and then sliding the throttle assembly along the handle bars (left or right). Once done, firmly tighten the clamp screws to OEM torque specifications. This adjustment is generally not necessary.

Installation steps

Step '

Completely remove the right side OEM bar-end weight by pulling the bar-end weight outwards. This will cause the bar-end weight to pop out of the handle-bar as shown in picture 1. Repeat this step for the left hand side OEM bar-end weight.

Step 2

Place the 131 thrust washer onto the end of the plastic throttle sleeve, making sure that the spigot of the thrust washer makes contact with the plastic throttle sleeve as shown in **picture 2**.

Note: To enable improved functionality, it is recommended (not essential) to apply very light smear of Automotive grease or Petroleum jelly to the friction face of the thrust washer (See **figure 1** at the back of the page).

Step 3

Slide the Kaoko bar-end weight (RHS) into the handlebar as seen in picture 3, making sure that the Kaoko stem flat is placed over the handlebar seam. The stem flat is designed to allow enough room for the Kaoko bar-end stem to slide into the handlebar without the handlebar seam causing obstruction.

Note: Make sure that the friction nut is adjusted up against the shoulder of the Kaoko body as shown in figure 2 on the back of the page.

Step 4

Completely tighten the M6x65 CAP screw to secure the Kaoko bar-end weight (RHS) inside the handlebar as shown in picture 4.

Step 5

Slide the Kaoko bar-end weight (LHS) into the handlebar as seen in picture 5, making sure that the Kaoko stem flat is placed over the handlebar seam.

Step 6

Completely tighten the M6x40 CAP screw to secure the Kaoko bar-end weight (LHS) inside the handlebar as shown in picture 6.

Step 7

Carefully set rotational resistance of the friction nut by tightening/loosening the grub screw by small adjustments using the 2mm allen key provided in the Kaoko Kit. Take care not to over tighten risking damage to threads. The nut should have fairly firm rotational resistance. See under Maintenance below.

Operating Instructions

The Friction Nut has a left hand thread. In readiness for engagement, the Friction Nut must be adjusted so that it makes light contact against the thrust washer. For correct engagement and disengagement of the unit, the friction nut should be able to rotate between a quarter and a full revolution.

To Engage: While rolling on the throttle, the Friction Nut can be gripped between the small finger and palm of hand. This action tightens the nut and provides sufficient friction to set the throttle to the desired opening. (The friction is such that the rider may still open and close the throttle. The throttle simply has a slight rotational stiffness.)

To Disengage: While rolling off the throttle, grip the Friction Nut between small finger and palm of hand.


VERY IMPORTANT!! The throttle should open and snap closed freely when correctly disengaged.


Note: The Grub Screw is set to provide the necessary resistance on thread of friction nut. This may be adjusted periodically to take up wear.

Maintenance: Remove kit annually. Unscrew Friction Nut and brush clean threads with a mild soap. Apply petroleum jelly to threads and assemble.

Adjust grub screw to desired operating resistance. (O-Ring cushion: 19.6mm I.D. x 2.4mm section — if replacement is required)







INDEMNITY

KAOKO ACCESSORIES AND PRODUCTS

Express Disclaimer, Exclusion of Liability, Indemnity and Safety Warning:

- 1. The accessories and products supplied by $KAOKO_{TM}$ are aftermarket accessories and products.
- 2. The use and employment of such accessories and products is at the sole risk and discretion of the user.
- 3. The user of such accessories and products further indemnifies $KAOKO_{TM}$ and its representatives against all claims and losses arising (including personal injuries, death, damage to property and any other losses) and involving such accessories and products.
- 4. KAOKO_{TM} provides no warranty on accessories and products that it produces and distributes and does not aver that these accessories and products are fit for the purposes for which same are manufactured and intended.
- 5. KAOKO_{TM} assumes no responsibility for and liability regarding any and all defects, deficiencies or otherwise in and attributed to its motor accessories and products.
- 6. KAOKO_{TM} further assumes no responsibility for and liability regarding any prospective losses and claims for damages; be same actual, consequential or contingent and which in any way are associated with its motor accessories and products. In circumstances where accessories and products supplied are found to be of defective manufacture, $KAOKO_{TM}$ reserves its rights to replace such defective accessories and products, alternatively; effect a financial refund equivalent to the purchase price of such accessories and products as at the date of placement of order.
- 7. The application and affixing of KAOKO_{TM} accessories and products to vehicles may necessitate or result in modifications being undertaken and this may result in manufacturer or otherwise warranties provided on such vehicles being affected and for that matter voided. In circumstances where the above occurs. KAOKO_{TM} expressly denies being accountable regarding any liability and losses ensuing.
- 8. The application and affixing of KAOKO_{TM} accessories and products may further result in usual vehicle operations and safety features being modified, overrode and for that matter discarded.
- 9. KAOKO_{TM} accessories and products ought to be used by experienced and responsible riders only. The onus rests on the user of such KAOKO_{TM} accessories and products to become properly familiarised with and understand the nature, operation and scope of the above accessories and products and further ensure that same are correctly affixed and used at all times and further not abused.
- 10. Misapplication and abuse of such accessories and products can endanger the user and result in injury or death and further constitute safety hazards.
- 11. The affixing and usage advices provided by KAOKO_{TM} are for guidance purposes only and do not constitute specific fitment instructions. The onus rests on the user to ascertain and ensure proper and professional affixing and fitting to vehicles of the accessories and products and in seeking suitably qualified assistance in dealing with the above.
- 12. Prior to resorting to using $KAOKO_{TM}$ accessories and products, it is recommended that the user seek independent advice regarding the integrity and suitability of above accessories and products and in fulfilling the user's needs.
- 13. KAOKO_{TM} accessories and products should only be fitted to new motorcycles and those that are in original condition, having not been involved in any accidents, being dropped, damaged or the subject of repair. Where KAOKO_{TM} accessories and products are fitted to motorcycles not in original condition there is the risk that the operation of KAOKO_{TM} accessories and products will be compromised and damaged. In all of the above events, KAOKO_{TM} does not accept liability.