



Fitting Instructions for RAD0103BK/TI Radiator Guard
HONDA CBR600F 2011



In This Kit There Should Be
1x Radiator Guard (RAD0103BK)
2 x Cable/Zip Tie
2x 100mm Lengths of self adhesive Foam



- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator.
- Undo and remove both upper radiator-mounting bolts shown in picture above left (to do this it is easier and quicker to remove side fairings).
- Offer the radiator guard into position and using original upper bolts and secure the guard and radiator into position.
- Using the two cable/zip ties secure the guard into position in two places as shown above right.
- Tighten all bolts.
- Refit fairings.

ISSUE 1 29/03/2011 (NSY)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect.

R&G Racing
Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.



FRANCE
Instructions de montage de la protection de radiateur
RAD0103BK/TI
HONDA CBR600F 2011

Ce kit contient
1x Protection de radiateur (RAD0103BK-TI)
2x bandes de mousse 100 mm
2x câbles de serrage



- Pour fixer la protection de radiateur sur la moto, vous devez couper des morceaux de mousse de 10 mm et les coller sur l'arrière de l'armature de la protection (de manière à ce qu'ils soient positionnés entre le radiateur et la protection R&G).
- Dévisser et enlever les deux vis de fixation du radiateur (fixations hautes- photo de gauche) pour votre confort, nous vous conseillons de retirer les carénages latéraux de la moto.
- Placer la protection et utilisez les vis de fixation d'origine pour maintenir la protection sur la moto.
- A l'aide des câbles de serrage livrés dans le kit, fixer la partie basse de la protection R&G sur la moto.(voir photo de droite ci-dessus.)
- Serrer les vis
- Remonter les carénages latéraux (si nécessaire)