

FITTING INSTRUCTIONS FOR CP0251BL AERO CRASH PROTECTORS BMW K1300 R '09'-



PICTURE 'A'





REAR OF BIKE

FRONT OF BIKE PICTURE 'C'



PICTURE 'D'

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – the rubber washers should be thrown away!

You will need the following tools to complete this job.

8mm ring spanner Socket set to include T50 male and 17mm A/F socket and wrench. Torque wrench to be used at 40NM.



Near side (left side as you sit on bike)

- Remove top front *engine to frame* bolt and OEM crash protector/spacer as arrowed in picture 'A' (using T50 male socket).
- Slide one of the flat washers onto the either bolt followed by a shake proof washer.
- Next, slide one of the crash protectors onto the bolt.
- Finally, slide the longer spacer onto the bolt with the larger diameter next to the protector.
- Offer this assembly up to frame mount and tighten bolt until you feel some compression from inside the protector using 17mm socket and wrench. PLEASE NOTE BOBBIN MUST BE POSITIONED AS IN PICTURE 'C' ABOVE WITH BIGGER END TOWARD FRONT OF BIKE. Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Do not overtighten as damage can occur to the bike. Do not exceed 40nm of torque.
- If not already fitted fit bubble sticker into recess of bobbin cap.
- Fit bobbin cap into bobbin.

Off side (right side as you sit on bike)

- Remove top front *engine to frame* bolt and OEM crash protector/spacer as arrowed in picture 'B' (using T50 male socket).
- Using an 8mm ring spanner undo the pinch bolt on the frame so that you can remove the aluminium spacer. (As shown in picture 'D' above).
- Slide one of the flat washers onto the remaining bolt followed by a shake proof washer.
- Next, slide the crash protectors onto the bolt.
- Finally, slide the shorter spacer onto the bolt.
- Offer this assembly up to frame mount and tighten bolt until you feel some compression from
 inside the protector using 17mm socket and wrench. PLEASE NOTE BOBBIN MUST BE
 POSITIONED AS IN PICTURE 'C' ABOVE WITH BIGGER END TOWARD FRONT OF
 BIKE. Turn a little more so that you feel the compression increase slightly. Then apply a quarter
 turn. Do not overtighten as damage can occur to the bike. Do not exceed 40nm of torque.
- If not already fitted fit bubble sticker into recess of bobbin cap.
- Fit bobbin cap into bobbin.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in resellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

