



**Fitting Instructions for OCG0006 OIL-COOLER Guard  
DUCATI HYPERMOTARD 796 2010-  
DUCATI HYPERMOTARD 1100 2008-2009**



**PICTURE 1**



**PICTURE 2**

**In This Kit There Should Be**  
**1x Oil-cooler Guard (OCG0006).**  
**1x 100mm Length of self adhesive Foam.**  
**2x 4mm Cable ties x 220mm long.**

- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the oil-cooler guard frame, so that they sit between the radiator guard and the radiator.
- Remove the two bottom oil-cooler mounting bolts in position arrowed in picture 1.
- Fit the radiator guard and secure to bottom mounting brackets using original bolts as shown in picture 1.
- Secure the top of the oil-cooler guard using the cable ties supplied as shown in picture 2.



#### **CONSUMER NOTICE**

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

#### **R&G RACING RETURNS POLICY (NON-FAULTY GOODS)**

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 [www.rg-racing.com](http://www.rg-racing.com) Email: [info@rg-racing.com](mailto:info@rg-racing.com)



**FRANCE**  
**Instructions de montage de la protection de radiateur d'huile**  
**OCG0006**  
**DUCATI HYPERMOTARD 796 2010-**  
**DUCATI HYPERMOTARD 1100 2008-2009**

**Ce kit comprend:**  
**1x protection (OCG0006).**  
**1x bande de mousse adhésive 100mm.**  
**2x colliers de serrage x 220mm long.**

- Pour fixer la protection de radiateur sur la moto, vous devrez couper et coller des morceaux de 10 mm de mousse au dos de la protection. Ces morceaux de mousse se positionneront entre la protection et le radiateur.
- Enlever les 2 vis de fixation qui retiennent le radiateur (voir photo 1)
- Placer et fixer la protection de radiateur sur le radiateur, utilisez les vis d'origine pour fixer les fixations basses.
- Fixer ensuite les fixations supérieures à l'aide des colliers de serrage livrés dans le kit. (voir la photo 2).



**Montageanleitung für den OCG0006 ÖLKÜHLERSCHUTZ  
DUCATI HYPERMOTARD 796 2010-  
DUCATI HYPERMOTARD 1100 2008-2009**



**ABBILDUNG 1**



**ABBILDUNG 2**

**Dieser Kit enthält:**  
**1x Ölkühlerschutz (OCG0006).**  
**1x 100mm selbstklebender Schaumstoffstreifen**  
**2x 220 mm Kabelbinder**

- Um den Ölkühlerschutz am Motorrad zu montieren, schneiden Sie zuerst die mitgelieferten Schaumstoffstreifen in 10 mm breiten Streifen und kleben Sie diese auf der Rückseite des Ölkühlerschutzes, so dass sie zwischen dem Ölkühlerschutz und dem Ölkühler angebracht sind.
- Entfernen Sie die zwei unteren Montageschrauben, die in Abbildung 1 markiert sind.
- Montieren Sie den Ölkühlerschutz, den Sie mit den Originalschrauben an den unteren Montagehalterungen befestigen – siehe Abbildung 1.
- Verwenden Sie die mitgelieferten Kabelbinder, um den Ölkühlerschutz oben zu befestigen – siehe Abbildung 2.