

# FITTING DIAGRAM FOR LOW POWER INDICATOR AND LOAD BALANCING RESISTOR

IMPORTANT: Before connecting your indicators please ensure you understand the diagram below.

